

### **Table of Contents**

Safety Instructions 01
Parts List03
Under Bed View04
Electronics Overview
Installation
Wireless Remote Control
Remote Pairing 11
Memory Setting 12
Setting Up Two Bases. 13
Headboard Brackets Installation 14
Trouble Shooting 15

### **Safety Instructions**

#### Safety Disclaimer

Thank you for purchasing a Bossbeds adjustable bed base. For your safety, please read all instructions carefully before using this adjustable base. Save these instructions for future reference.

#### Attention:

Keep the base unplugged from the electrical outlet before operating any part of the base. To prevent the risk of electric shock, always unplug the base before cleaning. For your safety, ensure the base is in a flat position with all motors turned off, disconnected from the power source, and keep the power cord away from heated surfaces.

If the power cord or plug becomes damaged, or if the bed base is wet or not working properly, stop using the bed base and contact customer service

This bed base is intended to be used only as described in this manual. Do not use any accessories/attachments that are not recommended by the manufacturer. Close supervision is required when the bed base is used by or near children, convalescents or disabled persons.

#### Electrical Safety: Connect to a surge protector (not included).

Please ensure you connect the base properly to the power supply. Any incorrect power connection may cause electric Shock or Fire. FOR OPTIMAL SAFETY, YOUR ADJUSTABLE BED SHOULD BE PLUGGED INTO A SURGE PROTECTOR (not supplied with this adjustable bed). Always unplug this adjustable bed frame from the electrical outlet before any cleaning or maintenance of the bed frame. To safely disconnect, remove the plug from the outlet. Keep cord away from heated surface. Use only indoors.

The control box, motors, and remote (except battery compartments) should not be opened or tampered with. Opening or tampering with these components without authorization will void the warranty.

#### In-Home use only

Bossbeds adjustable bed bases are designed exclusively for in home use only. Do not use this base with oxygen therapy equipment or near explosive gases.

#### **Pacemaker Notice:**

This bed base contain noedymium magnets which may interfere with magnetic fields of devices such as pacemakers, ICD'S etc. Some pacemakers may falsely interpret the optional massage vibrations as movement or exercise. The owner of such medical devices should consult their physician before using this product.

#### **Children and Pets:**

This product is designed to be used by an adult. Do not allow children to operate this bed without adult supervision. Immediately dispose of all packing materials as they can pose a smothering risk to children and pets. Injury could occur if children or pets are permitted to play on or under the bed.

### **Safety Instructions**

#### **Product Ratings:**

The lift motors are not designed to operate continuously for more than (2) minutes in an (18) minutes time period. Attempting to circumvent or exceed this rating will shorten the life expectancy of the product and may void the warranty.

#### Weight Limits:

This product is not rated to support weights exceeding 385 kgs including the mattress and bedding The base will structurally support this weight, provided it is evenly distributed across the bed base. The adjustable base is not designed to support or lift this amount in the head or foot sections alone. Exceeding this weight restriction could damage the bed and/or cause injury and will void the warranty.

#### Acoustics:

The massage function will emit a noticeable tone during operation. As the massage intensity level is increased, the tone will intensify. The volume of this tone is directly related to the location environment. For example, when demonstrated in a show room, the surrounding environmental noise will cover some of massage noise. However, when installed in a home setting with wooden floors, carpeted or not, the massage volume will be more noticeable. In normal base operation, the legs support of the base will create a contact noise with floor. When entering, exiting, or shifting weight on the base, this contact noise may be louder as the legs make contact. This is normal.

#### Fabric Care:

To prolong the life of your fabric, protect it from direct sunlight whenever possible. For spot cleaning, wipe area with a light damp sponge or vacuum with a soft brush attachment to remove particles. Keep at a minimum of 30cm (12 inches) away from direct heat sources. For deeper cleaning, blot liquid spills with a clean dry cloth. Wipe with a clean cloth dampened with warm water. Do not moisten excessively. A soft bristle brush may be used to remove ingrained soil. Avoid scratching by brushing gently. Wipe with a clean cloth dampened with warm water to remove residues. Dry in a shaded area away from direct heat. If persistent marks remain visible after cleaning, seek professional advice.

#### FCC Compliance:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

To comply with the FCC RF exposure requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding RF exposure requirement an void user's right to operate the device.

Radio Frequency: 2.4GHz



## Parts List

Ensure you have received all the parts listed below before discarding the packing materials.

#### Parts List:

- A) Wireless Remote Control and AAA batteries [3]
- B) Legs and Washers (Note that the legs are two piece legs) [4]
- C) Mattress Retainer [1]
- D) Power Supply [1]
- E) Power Cord [1]
- F) Headboard Bracket [2] (Optional)
- G) Headboard T-Bar [2] (Optional)
- H) Large Washers [2] (Optional)
- I) Long Bolts M8 [4] (Optional)
- J) Short Bolt [8] (Optional)
- K) Small Washers [12](Optional)
- L) Hex Key [1] (Optional)
- M) Sync Cable [1] (Optional)
- N) Long Bolts M10 [2] (Optional)







### Installation

#### STEP 1: Remove packing materials

Put the bed base in a desired place with the bottom of the box facing up. Remove box cover, take out all of the packing materials and put aside, Make sure not to puncture the bed with any sharp objects.





#### STEP 2: Remove the bed from the box

Remove the bed base from the box keeping the bottom of the base facing upwards. Install the 4 legs to the four corners as shown. Tighten the legs by hand. Ensure the legs are secured tightly.

P.S. Install the headboard brackets at the same time if attaching to a headboard. See the page 16.

#### STEP 3: Overturn the bed base carefully

Carefully turn the base over using two people. Do not lay the base on its side to prevent damage to the side button, fabric or legs.



Plug the power cord into the power supply as shown.







## Installation

#### STEP 5: Remote

After the base is connected to the power supply, install three AAA batteries into the remote battery compartment. See pages 9 and 10 to learn how to operate the remote.



#### STEP 6: Install mattress retainer

\*Locate the mattress retainer as shown below [1)];



Insert the mattress retainer into the hooks at the foot of the bed as shown [2)]. Slide the mattress retainer into place. Ensure it is securely tightened [3)].







#### BOSS Wireless Remote Control Adjusting Features The HEAD UP/DOWN button . ^ raises/lowers the head section of the base POSITIONS 5 ^ The FOOT UP/DOWN button raises/lowers the foot section of the base ZG \*^ FLAT The HEAD TILT UP/DOWN button MEMORY MEMORY \*\*\* ŝ customizes the level of head support SSAG Е MA 10MIN 20MIN 30MIN TIMER/ ALL OFF FOOT HEAD The LUMBAR UP/DOWN button ~ ^ customizes the lever of lumbar 3 1111 support č One touch ZERO GRAVITY preset BO ZG position, adjust your legs to a higher level than your heart, to help relieve pressure off the lower back and promote body circulation The one touch FLAT button returns FLAT the head and foot sections to a horizontal position. One touch MEMORY A button MEMORY allows you to preset your favorite A postion. One touch MEMORY B button MEMORY allows you to preset your favorite в postion. http://bossbeds.ca



## **Remote Pairing**

Attention: All bases are set to the different DIP of the remote for easier use. You need to pair your remote if you need one remote controls two bases simultaneously. If using only one base normally, proceed to page 14.

STEP 1:

Press and hold the "LINK BUTTON" on the control box untill the LINK LED fashes, then release the "LINK BUTTON"



### **Memory Setting**

#### STEP 1:

Ensure the base is connected to the power supply correctly and the remote control works properly. Ensure the base is in the Flat position. Make sure the massage, LED light and other functions are turned off.

#### STEP 2:

Adjust the HEAD and FOOT to your desired position. Press the "TIMER/ALL OFF" button until all buttons on the remote are flashing.



#### STEP 3:

While the buttons are flashing, press one of these three buttons including "MEMORY A"/"MEMORY B"/"ZG" until the flashing stops. The selected MEMORY FUNCTION is now set.



## **Setting Up Two Bases**

Sync Cord

20111 30000

#### How to operate two bed bases simultaneously

#### STEP 1:

The sync cord is needed when connecting two CK or TXL bases together.

#### STEP 2:

How to synchronize the two bases: Use the sync cord connecting base A control box in sync port with base B sync port.

Sync port: SYNCHRO CNTL!

#### STEP 3:

After synchronization, any of the remotes can control the two bases synchronously.

#### How to disable the synchronizing function

Unplug the sync cord connecting the two bases. The sync function is now disabled.



### **Headboard Brackets Installation**

#### STEP 1:

Open the headboard bracket accessory package and confirm that all the pieces listed below are included: Headboard Brackets [2] Headboard Connecting Components [2] Short Bolts (8) Long Bolts M8 [4] Large Washers [2] Small Washers [12] Hex Key [1] Long Bolts M10 [2]

#### STEP 2:

Install the headboard bracket (F) using one long bolt (M10) and one large washer. Install as per the picture to the right. Use the Hex Key to tighten the bolts. Repeat this process for the other side of the base.



#### STEP 3:

Attach the headboard T-Bar (G) to the headboard bracket(F) using 4 short bolts and 4 small washers as per the picture to the right. Use the Hex Key to tighten the bolts. Repeat this process for the other side of the base.







#### STEP 4

The remaining 4 pieces of long bolts (M8) and 4 pieces of small washers can be used to attach the headboard bracket to your headboard.

## **Trouble Shooting**

If one or more functions on the bed base have stopped operating, please check the bed as follow:

 $\odot$  Check under the bed base to verify that the wired connections are secure and that there are no cords or bedding obstructing the movement of the base.

© Check to see if the bed base is connected to the power supply correctly. Make sure the power supply is connected to the outlet.

© Ensure the batteries in the remote are new and operable.

◎ If the power supply is working correctly, unplug the base for 1 hour to reset the electronic components.

 ${\ensuremath{\mathbb O}}$  After the electronic components have been reset, follow the REMOTE SETTINGS steps on page 13 to reset the base.